

## Sound functions - NSWGR 422 class



Decoder address: \_\_\_\_\_

- F0 Directional headlight
- F1** Prime-mover start-up & shut-down
- F2 Long horn
- F3 Coupler crash and release
- F4 Dynamic brake
- F5 *Drive hold (FT)*
- F6 *Brake application (FT)*
- F7 Shunting mode
- F8 Ratchet handbrake
- F9 Short horn
- F10 Curve squeal
- F11-14 Aux 1-4
- F15 Sanders



[www.dccsound.com](http://www.dccsound.com)  
[mike.dccsound@gmail.com](mailto:mike.dccsound@gmail.com)  
0487 475 222