

# DCCSOUND.COM



**Authorised reseller**

## Sound functions: 422 class

Decoder address: \_\_\_\_\_

F0: Headlight (directional)

F1: Prime mover start-up and shutdown

F2: Long horn

F3: Coupler crash, brake lines & coupler bar release

F4: Dynamic braking

F5: Manual notching up

F6: Manual notching down

F7: Switching mode

F8: Manual handbrake

F9: Short horn

F10: IBV air brake release

F11: Aux 1 lighting

F12: Aux 2 lighting

F13: Engine room door

[www.dccsound.com](http://www.dccsound.com)

[mike.dccsound@gmail.com](mailto:mike.dccsound@gmail.com)

0487 475 222