



## Sound functions: 80 class

Decoder address: \_\_\_\_\_

F0: Headlight (directional)

F1: ALCo 12-251CE prime mover start-up, shutdown

F2: Horn long

F3: Coupler release and coupler crash

F4: Dynamic brakes

F5: Manual notching up

F6: Manual notching down

F7: Condensate release valve

F8: Cab door closure

F9: Horn short

F10: Air brake release

F11: Aux 1 lighting

F12: Aux 2 lighting



**Authorised reseller**

[www.dccsound.com](http://www.dccsound.com)

[mike.dccsound@gmail.com](mailto:mike.dccsound@gmail.com)

0487 475 222