



## Sound functions: DERM

Decoder address: \_\_\_\_\_

- F0: Directional headlight
- F1: Prime-mover start-up & shut-down
- F2: Long horn
- F3: Coupler crash and release
- F4: Guard's whistle
- F5: Manual notching up
- F6: Manual notching down
- F7: Shunting mode (1/2 motor speed)
- F8: Manual handbrake
- F9: Short horn
- F10: IBV air brake release
- F11: Aux 1 lighting
- F12: Aux 2 lighting



**Authorised reseller**

[www.dccsound.com](http://www.dccsound.com)

[mike.dccsound@gmail.com](mailto:mike.dccsound@gmail.com)

0487 475 222