

DCCSOUND.COM



Sound functions: VR F class

Default decoder address: _____

F0: Headlight (directional)

F1: EE 6KT prime mover start-up and shutdown

F2: Playable whistle

F3: Coupler release and coupler crash

F4: Lube oil hand priming

F5: Cab door closing

F6: Taildisc flip

F7: Sand box lid access

F8: EE 6KT "cold start" (activate F8 before F1)

F9: Short whistle

F10: Air brake release & set (automatic application)

F11: Aux 1 lighting

F12: Aux 2 lighting



Authorised reseller

www.dccsound.com

mike.dccsound@gmail.com

0487 475 222