



Authorised reseller

Sound functions: Diesel

Default decoder address: _____

- F0: Directional headlight
- F1: Prime-mover(s) start-up & shut-down
- F2: Long horn
- F3: Coupler crash and release
- F4: Low idle/Dynamic braking/Guard's whistle
- F5: Manual notching up
- F6: Manual notching down
- F7: Shunting mode (1/2 motor speed)
- F8: Manual handbrake
- F9: Short horn
- F10: IBV air brake release
- F11: Aux 1 lighting
- F12: Aux 2 lighting

www.dccsound.com

mike.dccsound@gmail.com

0487 475 222