

Sound functions - VR RT class



Decoder address: _____

- F0 Directional headlight
- F1** Prime-mover start-up & shut-down
- F2 Long horn
- F3 Coupler crash and release
- F4 -
- F5 Low gear / *Heavy Load (FT)*
- F6 *Brake application (FT)*
- F7 Shunting mode
- F8 Windscreen wiper
- F9 Short horn
- F10 Curve squeal
- F11-13 Aux 1-3
- F14 Cab door
- F15 Sanding box
- F16 Taildisc



www.dccsound.com
mike.dccsound@gmail.com
0487 475 222