

## Sound functions – V/line Vlocity



Decoder address: \_\_\_\_\_

- F0 Directional headlight
- F1** Prime-movers start-up & shut-down
- F2 Country horn
- F3 Scharfenberg coupler engage and release
- F4 Door closure
- F5 Auxillary power Genset (activate before F1)
- F6 *Brake application (FT)*
- F7 City horn
- F8 TPWS tone & radio check (activate before F1)
- F9 Mixed horn
- F10 Curve squeal
- F11 Interior lighting
- F12 Prime mover #2 start-up & shutdown
- F13 Country horn (short)
- F14 City horn (short)
- F15 Sanders

[www.dccsound.com](http://www.dccsound.com)  
[mike.dccsound@gmail.com](mailto:mike.dccsound@gmail.com)  
0487 475 222